



## Please refer to this checklist before and after Dec-Tec installation

### Before Dec-Tec Installation:

- Please see **CM001 – Basic Installation Guide – Wood Substrate V.03**. Follow the guide for a successful installation.
- Check local building codes where applicable.
- Follow instructions on all product labels.
- Make sure you have all the tools needed to finish the project successfully. Refer to **CL003 – Dec-Tec Tools & Supplies Checklist v.01**.
- Dec-Tec does not recommend the use of any non-approved substrates. Use of any substrates other than those approved may VOID any warranty expressed or implied.
- The entire substrate must be structurally sound, dry, solid, and stable and properly prepared prior to installing the membrane.
- We recommend the substrate has a minimum of 1/4" per foot or 2% slope.
- Ideal moisture content (MC) of substrate / plywood at the time of installation is up to 14% @ 70% relative humidity / 68 deg. F (20 deg. C).
- In a multi panel application be sure that there are no dye lot variances.
- Ensure to dry fit and acclimate the membrane prior to installation. In a multi panel applications ensure that the directions of the membrane is the same. This is accomplished by looking at the directional arrows located at the back of the membrane.

### After Dec-Tec Installation:

- Make sure all joints that are thermally heat welded are completed and all seams are checked with a seam checker.
- Make sure the membrane does not come in contact with non-compatible products.
- On new construction, to avoid damage, always cover the Dec-Tec membrane with a protective surface after membrane is installed and prior to occupancy.
- Be sure to share the **AM001 - Dec-Tec Care & Maintenance Guide v.01** with the property owner.
- We recommend you register the warranty and provide a copy of the warranty to the property owner.