



## DECK DETAIL : BRICK SIDING - SAWCUT REGLET AND COUNTER FLASHING

### NOTES:

1. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH DEC-TEC INSTALLATION GUIDE, REFERENCE CM001.
  2. DRAWINGS NOT TO SCALE .
  3. DO NOT COVER MASONRY WEEPHOLES WITH FLASHING OR MEMBRANE.
  4. MIN. SLOPE 1/4":12" AWAY FROM THE BUILDING STRUCTURE.
  5. SKYLINE BUILDING SYSTEMS INC. DOES NOT ASSUME RESPONSIBILITY FOR ERRORS IN DESIGN, ENGINEERING, QUANTITIES OR DIMENSIONS. THE ARCHITECT, CONTRACTORS OR OWNER'S REPRESENTATIVE MUST VERIFY ALL DIMENSIONS, SIZES AND SUITABILITY OF DETAILS.
  6. THIS DRAWING IS THE PROPERTY OF SKYLINE BUILDING SYSTEMS INC. AND MAY NOT BE REPRODUCED WITHOUT WRITTEN CONSENT.
  7. VISIT [WWW.DEC-TEC.COM](http://WWW.DEC-TEC.COM) OR CALL 1-866-461-3914 FOR ADDITIONAL INFORMATION.
- \* MUST CONSULT LOCAL BUILDING CODE AND CONFORM TO BE COMPLIANT.